

Setting up your Super Combo Keyer II

Thank you for investing in the new Super Combo Keyer Version II! We trust that you will enjoy good service from this unit for many years.

Support for the SCK II is only an email away so if you have any queries please contact Bernie, ZS4TX at zs4tx@qsl.net

There are several ways to utilise the SCK II in a DX or contest environment so it is important that you know exactly what you want to achieve with the SCK II and how you are going to connect it before you proceed.

Connections to your computer may be especially complicated because of all the different operating systems and hardware configurations that are available.

Please do not hesitate to contact Bernie if you have doubts about any configuration or if the unit does not interface to your specific PC as advertised.

Studying long manuals are not everyone's favourite pastime! The SCK II is unfortunately **not** a "**plug and play**" device so unless you have extensive experience in SO2R and PC controlled CW and PTT keying it is **compulsory** that you at least read through the following documents available on the Internet:

A shortened setup guide can be found here:

http://www.zs4tx.co.za/sck/SCK_II_Com_LPT_Notes.pdf

The full manual is available on the following website:

http://www.zs4tx.co.za/sck/Super_Combo_Keyer_202.pdf

The *Super Combo Keyer II* is manufactured in South Africa.

Bernie van der Walt
PO Box 28691
Danhof
9310
Republic of South Africa

Distribution for North & South America is handled by:

Array Solutions
350 Gloria Road
Sunnyvale, Texas
75182, USA
